



SHERIDAN 3LT AIMABLE CM ORB SKU#578054

ASSEMBLY / INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions, as you may need them at a later date.

CAUTION

Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.

GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards.

If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician. Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions. Tools are required when install this fixture.

REQUIRED TOOLS


Philips screwdriver, installer tool (included)

ASSEMBLY AND INSTALLATION

Turn off the power at fuse or circuit breaker

1. Carefully unpack the fixture; lay out all parts on a clean surface.
2. Fasten the MOUNTING STRAP to OUTLET BOX using the provided OUTLET BOX SCREWS.
3. Tie ground wire from OUTLET BOX and from fixture to the GROUND SCREW on the MOUNTING STRAP.
Connect white wire from fixture to white wire (neutral wire) from supply circuit. Connect black wire from fixture to black wire (live wire) from supply circuit. Cover connections using provided WIRE CONNECTORS.
4. Place the CANOPY over the OUTLET BOX by pulling the NIPPLE all the way through the CANOPY; thread the LOCK NUT to the NIPPLE until the CANOPY is firmly held against ceiling.
5. Install the LED GU10 BULBS (included) to the SOCKETS by using the INSTALLER tool.
6. Adjust the SHADES to desired positions.

Turn on the power at fuse or circuit breaker.



ITEM#578054

**IF IN DOUBT ABOUT ELECTRICAL INSTALLATION,
CONSULT A LICENSED ELECTRICIAN.**

Customer Service: 1-800-558-8700